



*Clean gully of debris and measure for width, height and depth.*



*Measure MultiGrate and mark up for cutting using the moulded lines as a guide.*



*Using a power saw or angle grinder with a masonry disc cut grate to size.*



*Check fit and adjust where needed. Note that the grate can easily be handled by one person.*



*Adjust the grate to fit internal intrusions of the existing frame by using a small hand saw.*



*Drop grate into place and check for final fit - it should not rock or be proud of the roadway.*



*Two plastic snap-off wedges are supplied with each MultiGrate and provide a quick way to firmly secure the grate & prevent movement.*



*MultiGrate can be fitted well within 30 minutes and the entire works, from arriving on site to leaving can be completed in less than an hour by a single maintenance crew employee using simple tools and techniques. Looks like a normal gully grate but useless to thieves.*