

# Ultracrete Envirobred HA104 & QC10 Quick Set Concrete:

## *Reinstatement Guide for BT Covers and Frames*



An **INSTARMAC** Brand

### **Ultracrete Envirobred -**

Bed frame and cover with Ultracrete Envirobred bedding mortar as an alternative to polyester resin mortar.



### **Ultracrete QC10 F -**

Backfill void using Ultracrete QC10 F fast set, flowable, rapid strength concrete (as an alternative to polyester pourable resin bedding) to required level allowing for correct depth of wearing course.



# Ultracrete Envirobred HA104 & QC10 Quick Set Concrete:

## *Reinstatement Guide for BT Covers and Frames*



An **INSTARMAC** Brand

### Ultracrete SCJ-

Spray all vertical edges, including ironwork, with Ultracrete SCJ spray applied bitumen cold joint sealer to eliminate water ingress.



### Ultracrete Instant Road Repair -

Apply Ultracrete Instant Road Repair cold lay asphalt to surface and compact for a complete reinstatement

