

TOUGH PATCH® RAPID

INSTALLATION GUIDE

ULTRA
CRETE

An **INSTARMAC** Brand



1. Sweep away any loose debris



2. Sprinkle repair with water



3. Apply the product slightly proud of the repair



4. Spread the product out evenly



5. Sprinkle more water over the repair prior to compaction



6. Compact using a suitable tamping device

t: 01827 871871 e: ultracrete@instarmac.co.uk